

AT100G

Single Phase Direct DIN Rail

Energy Meter

User Manual V1.0



Hangzhou Antin Power Technology Co., Ltd

Statement

All rights reserved. Without the written permission of the Company, no part of this manual may be extracted, copied or reproduced in any form, or transmitted, or all the consequences shall be borne by the violator.

The Company reserves all legal rights.

The Company reserves the right to make changes in the specifications of the products described in this manual without prior notice. Before ordering, please contact us or your local agent for the latest specifications of this product.

Content

Chapter 1 Product Overview	- 1 -
1.1 Product Introduction	- 1 -
1.2 Product Features	- 1 -
1.3 Product Features	- 1 -
Chapter 2 Technical Specifications	- 3 -
2.1 Technical Parameters	- 3 -
2.2 Appearance/product dimensions and installation drawings	- 5 -
2.3 Wiring Diagram	- 6 -
Chapter 3 Operating Instructions	- 7 -
3.1 Startup Screen	- 7 -
3.2 Scrolling	- 7 -
3.3 Display Content	- 8 -
3.4 Setting Mode	- 11 -

English correspondence table of LCD segment code - 16 -

After-sales service - 17 -

Chapter 1 Product Overview

1.1 Product Introduction

AT100G series single-phase din rail energy meter is designed to collect, analyze and measure power parameters. AT100G series single-phase din rail energy meter can support the measurement and analysis of various power parameters, such as voltage, current, four-quadrant power parameters, power factor, bi-directional active and reactive power etc. This series of products have RS485 communication interface, the highest baud rate support 38400bps, support Modbus, DLT645 and other communication protocols, can easily realize remote data reading. Meanwhile, it adopts LCD display, which can view and set various measurement parameters locally, and the product has password protection function to ensure the data security of the product.

1.2 Product Features

- Up to 100A direct access
- Standard 2-module width, TH35-7.5 type din rail mount
- Touch key design
- Multi-functional parameter measurement
- Support bi-directional power metering
- Support 1-channel passive pulse output, 1-channel RS485 communication
- LCD full-view display, white backlight, backlight lighting time adjustable
- LCD display refresh time: 1 second, support manual page turning and automatic display rotation (can be set to switch)

1.3 Measurement and Display Content

- Voltage
- Frequency
- Current, current demand
- Power, maximum power demand and power factor
- Forward and reverse active energy
- Forward and reverse reactive power

1.4 Parameters to be set

- System password
- Demand statistics time
- Reset demand option
- Pulse parameters

Two pulse outputs for real-time power metering. The remote computer can realize the remote monitoring with the 485 communication output of the meter. RS485 serial communication.

The meter uses RS485 serial port and Modbus RTU communication protocol to provide remote monitoring and control functions, in addition, the 485 serial communication parameters can be modified through the menu.

Pulse output.

This instrument provides two pulse outputs for measuring active and reactive energy. The pulse setting parameters can be set through the setup menu.


Chapter 2 Technical Specifications

2.1 Technical Parameters

Technical Parameters		
Access type	Direct access	
Rated voltage	230V	
Voltage range	176~276V AC	
Current rating	10A	
Maximum current	100A	
Minimum current	0.5A	
Starting current	0.4% times of the rated current	
Power consumption	<2W/10VA	
Frequency	50/60Hz	
Pressure-resistant	4KV/1 min	
Pulse withstand voltage	6KV-1.2us	
Overload	30 times the maximum current - 0.01s	
Pulse output	1000imp/kWh (default)	
	1000/100/10/1 imp/kWh/kVarh (configurable)	
Display	LCD	
Precision	voltage	±0.5%
	current	±0.5%

	frequency	$\pm 0.2\%$
	Factor	$\pm 1\%$
	Active power	$\pm 1\%$
	Reactive power	$\pm 1\%$
	Apparent power	$\pm 1\%$
	Active electrical energy	1 级 ICE52053-21
		Class B EN50470-3
Reactive electrical energy	$\pm 1\%$	
Operation Environment	Operating temperature	$-25^{\circ}\text{C}\sim+55^{\circ}\text{C}$
	Storage temperature	$-40^{\circ}\text{C}\sim+75^{\circ}\text{C}$
	Reference temperature	$23^{\circ}\text{C}\pm 2^{\circ}\text{C}$
	relative humidity	0~95%RH, no condensation
	elevation	250m or more
	Warm-up time	10s
	vibration	10Hz~50Hz, IEC 60068-2-6,2g

2.2 Appearance/product dimensions and installation drawings




2.3 Wiring Diagram



Chapter 3 Operating Instructions


3.1 Startup Screen

The meter is powered on, and the LCD interface is fully displayed for 1s.



3.2 Scrolling







After the system initialization is completed, the meter displays the measured power value, and the total active energy is displayed by default. If the user wants to check other battery information, he can press the scrolling display button to view.








Press  the key to display the content in the following order:








Total active energy→ input active energy→ output active energy→ total reactive energy→ input reactive energy→ output reactive energy→ maximum power demand→ voltage→ current→ active power→ reactive power→ apparent

power→ power factor→ frequency→ pulse → communication address→ baud rate→ continuous operation time.


3.3 Display Content







	Total active energy Example: 70.00kWh
	Input active energy Example: 50.00kWh
	Outputs active energy Example: 20.00kWh
	Total resettable active energy
	Total reactive energy 例:10.00kVarh
	Input reactive energy 例:5.00kVarh






 <p>00005.00 ←kV arh</p>	<p>Output reactive energy 例:5.00kVarh</p>
 <p>Σ r 0000 149 kV arh</p>	<p>Total resettable Reactive energy</p>
 <p>Σ MD 6930 W</p>	<p>Total maximum power demand Example: 6930W</p>
 <p>219.5 V</p>	<p>voltage Example: 229.5V</p>
 <p>30.156 A</p>	<p>current Example: 30.156A</p>
 <p>4700 W</p>	<p>Active power Example: 4700W</p>
 <p>1030 V ar</p>	<p>Reactive power Example: 1030Var</p>







 <p>4811 VA</p>	Apparent power Example: 4811VA
 <p>PF 1.000</p>	Power Factor Example: 1.000
 <p>49.99 Hz</p>	Frequency Example: 49.99Hz
 <p>c5t 1000</p>	Pulse constant Example: 1000
 <p>Add 001</p>	Comm. Port Example: 001
 <p>bd 9600</p>	baud rate Example: 9600
 <p>100h</p>	Continuous running time







3.4 Setting Mode




Press the "Enter" key  and hold for 3s to enter the meter setting mode.

	Displayed when setting is correct
	Displayed ff the input information is incorrect
	password To enter the setup mode, the system needs to enter the login password. Default password: 1000
	Communication Port The default comm. port is: 001 Setting range: 001~247
	Press the "Enter" key and the first digit flashes. Press "Scroll" to change the value of the blink digit.
	baud rate Default value: 9600bps Setting range: 1200, 2400, 4800, 9600bps.

	<p>Press the "Enter" key, the red number flashes when it appears,</p> <p>press the "Scroll" key to change the setting value. Confirm that the changes are complete</p> <p>, press the "Enter" key to confirm the settings.</p>
	<p>Check digit</p> <p>Default: None</p> <p>Set range: None, Even, Odd</p>
	<p>Press the "Enter" key, the red number flashes when it appears,</p> <p>press the "Scroll" key to change the setting value. Confirm that the changes are complete</p> <p>, press the "Enter" key to confirm the settings.</p>
	<p>Pulse output</p> <p>Default: Export kWh</p> <p>Set Range: kWh / KVarh / Imp. Kwh / Exp.kWh / Imp.kVarh / Exp.kVarh</p>
	<p>Press the "Enter" key, the red number flashes when it appears,</p> <p>press the "Scroll" key to change the setting value. Confirm that the changes are complete</p> <p>, press the "Enter" key to confirm the settings.</p>

	<p>Pulse settings</p> <p>Default: 1000</p> <p>Setting range: 1000 / 100 / 10 / 1</p>
	<p>Press the "Enter" key, the red number flashes when it appears,</p> <p>press the "Scroll" key to change the setting value. Confirm that the changes are complete</p> <p>, press the "Enter" key to confirm the settings.</p>
	<p>Pulse Width setting</p> <p>Default: 100mS</p> <p>Setup range: 200 / 100 / 60ms</p>
	<p>Press the "Enter" key, the red number flashes when it appears,</p> <p>press the "Scroll" key to change the setting value. Confirm that the changes are complete</p> <p>, press the "Enter" key to confirm the settings.</p>
	<p>Demand time</p> <p>Default: 15 minutes</p> <p>Setting Range: 0 / 5 / 10 / 15 / 30 / 60</p>
	<p>Press the "Enter" key, the red number flashes when it appears,</p> <p>press the "Scroll" key to change the setting value. Confirm that the changes are complete</p>

	, press the "Enter" key to confirm the settings.
	The rolling display interval Default: 0S SETTING RANGE: 0 ~30S
	Press the "Enter" key, the red number flashes when it appears, press the "Scroll" key to change the setting value. Confirm that the changes are complete , press the "Enter" key to confirm the settings.
	Backlight hold time Default: 60 min Set Range: 0 (OFF)/5/10/20/30/60
	Press the "Enter" key, the red number flashes when it appears, press the "Scroll" key to change the setting value. Confirm that the changes are complete , press the "Enter" key to confirm the settings.
	Electricity Zeroing Press and hold "Enter" to enter the clearing interface
	Demand zeroing Press and hold "Enter" to enter the clearing interface.

	<p>Resettable energy zeroing</p> <p>Press and hold "Enter" to enter the clearing interface.</p>
	<p>Password settings</p> <p>Default: 1000</p>
	<p>Press the "Enter" key, the red number flashes when it appears,</p> <p>press the "Scroll" key to change the setting value. Confirm that the changes are complete</p> <p>, press the "Enter" key to confirm the settings.</p>

English correspondence table of LCD segment code

1	2	3	4	5	6	7	8	9	0	A	B
1	2	3	4	5	6	7	8	9	0	A	B
C	D	E	F	G	H	I	J	K	L	M	N
C	d	E	F	G	H	I	J	K	L	M	N
O	P	Q	R	S	T	U	V	W	X	Y	Z
O	P	Q	R	S	T	U	V	W	X	Y	Z

After-sales service

1. If the user does not understand the description in the manual during installation and commissioning, please contact the aftersales team.
2. The company's technology is ready to answer product-related questions.
3. The problems arising in the use of the product will be replied within one working day.
4. Our company has a one-year free warranty for the above products from the date of sale.

Technical descriptions are subject to change without notice

Hangzhou Antin Power Technology Co., Ltd.

R&D headquarters: 8th floor, Lufang Science and Technology Innovation Building, Xihu District, Hangzhou City, Zhejiang Province

Intelligent manufacturing base: 4th Floor, Building 3, Block C, Qinglan Science and Technology Innovation Park, Xihu District, Hangzhou City, Zhejiang Province

Email: sales@china-antin.com

Website: <http://www.china-antin.com>